



Activating Category 2 GO GOP Functions in CORES

Please follow the instructions below to submit a request to add a Category 2 Generator Owner and/or a Generator Operator Scope (Function) in the Centralized Registration ERO System (CORES).


- Log into the [ERO Portal](#).
- Select the applicable entity from the dropdown box located at the top right side of your menu options.
- Select **My Entity -> CORES**.



- Select the **Entity Scopes** section.



- To “Activate” a Category 2 Generator Owner and/or Generator Operator Scope (Function), select the **Add Scope** option and fill out all required fields.
 - Enter the applicable required fields: **Function, Proposed Effective Date, Region, Category, Jurisdiction, and Test Power Sync Date.**
 - Include a **Note** that explains the reason for the registration change request.
 - Select the **Submit** button.

 **Create** ✕

Function *
Generator Owner (GO) ✕ 🔍

Proposed Effective Date *
5/15/2026 📅

Region *
WECC ✕ 🔍

Category *
Category 2 ▼

Jurisdiction *
United States ✕ 🔍

Inactive Date
📅

Submitted By
Abby Fellingner

Note

Power Sync

Test Power Sync Date *
📅

Submit

Additional Information:

- In accordance with phase 3 of the Inverter-Based Resources (IBR) Registration Initiative the Proposed Effective Date should be 5/15/2026 if the Category 2 asset is operational on or before 5/15/2026.
- Please enter the initial **Test Power Sync Date** related to your first operational Category 2 generation asset.
- If you are activating the Category 2 Generator Owner and Generator Operator Scopes, repeat the process above to add the other Scope/Function.

- Select the **Functional Mapping** section and enter the applicable relationships:

A vertical sidebar menu with nine items, each preceded by a green checkmark. The items are: Basic Information, Upstream Holding Companies, Contact Roles, Entity Scopes, Functional Mapping, Coordinated Oversight, CFR, JRO, and Comments and Attachments. The 'Functional Mapping' item is circled in red.

- Select the **Add Mapping** button.

The 'Functional Mapping' page interface. At the top left, there is a breadcrumb trail: Home / CORES / Functional Mappings. Below this, there are two bullet points: 'This form is used for updating an existing registered entity's functional mapping. Functional mapping maps the existing registered entity to other registered entities on a functional basis.' and 'Training Link'. The main heading is 'Functional Mapping'. To the right of the heading is a blue 'Add Mapping' button, which is highlighted with a red rectangle. Below the heading is a table with the following data:

NERC Number (Parent Entity)	Parent Entity	Region	NERC Number (Entity)	Entity	Function	Description	Created On
V8000006	Test Entity	Texas RE	NERC04056	Electric Reliability Council of Texas, Inc.	Balancing Authority		1/19/2023 8:18 PM

On the right side of the page is a vertical sidebar menu with nine items, each preceded by a green checkmark. The items are: Basic Information, Upstream Holding Companies, Contact Roles, Entity Scopes, Functional Mapping, Coordinated Oversight, CFR, JRO, and Comments and Attachments. The 'Functional Mapping' item is highlighted with a red rectangle.

- Add the following information:
 - **Function** you are mapping to.
 - WECC as the **Region**.
 - The **NCR ID** (Entity Name) that you are mapping to for that applicable Function.
 - **Notes** about the entity mapping relationship (if applicable).
 - Select **Submit**.
- Repeat process for each applicable mapped function referenced below.

*****MAPPING REQUIRED*****


- Enter the applicable entity mapping relationships.
 - As a Category 2 GO or a Category 2 GO/GOP, please enter the following mapped functions related to your generation asset(s):
 - Balancing Authority (BA)
 - Generator Operator (GOP)
 - Planning Coordinator (PC)/Planning Authority (PA)
 - Reliability Coordinator (RC)
 - Transmission Owner (TO)
 - Transmission Operator (TOP)
 - Transmission Planner (TP)
 - As a Category 2 GOP, please enter the following mapped functions related to the generation asset(s) your organization operates:
 - Balancing Authority (BA)
 - Reliability Coordinator (RC)
 - Transmission Operator (TOP)



The screenshot shows a web form titled "Create" with a close button (X) in the top right corner. The form contains the following fields:

- Function**: A text input field with a red asterisk and a search icon (magnifying glass) on the right.
- Region**: A text input field with a red asterisk and a search icon (magnifying glass) on the right.
- NCR**: A dropdown menu with a checkmark icon on the right.
- Notes**: A large text area for entering notes.
- Submit**: A blue button at the bottom left.

- Select the **Comments and Attachments** section.



A vertical sidebar menu with eight items. Each item has a green checkmark to its left. The items are: Basic Information, Upstream Holding Companies, Contact Roles, Entity Scopes, Functional Mapping, Coordinated Oversight, CFR, JRO, and Comments and Attachments. The 'Comments and Attachments' item at the bottom is circled in red.


✓	Basic Information
✓	Upstream Holding Companies
✓	Contact Roles
✓	Entity Scopes
✓	Functional Mapping
✓	Coordinated Oversight
✓	CFR
✓	JRO
✓	Comments and Attachments

- Select the **Add Comment** button.



A screenshot of the 'Comments and Attachments' section. At the top, the title 'Comments and Attachments' is displayed. To the right of the title is a blue button labeled 'ADD COMMENT', which is circled in red. Below the title is a table with the following headers: Comment, Type, Created On (with an upward arrow), Created By, and Modified On. Below the table is a yellow message box that says 'There are no records to display.'

- Include a comment about your submission (like submitting a list of all GO GOP Assets (Category 1 and Category 2)).
- Attach the latest copy of your **ERO Enterprise GO GOP Asset Verification Form**.
- Select **Submit**.



The image shows a 'Create' form with a title bar containing a pencil icon and the word 'Create' on the left, and a close button (X) on the right. The form has two main sections highlighted with red circles. The first section, labeled 'Comment', contains a large text input area. The second section, labeled 'Attach a file', contains a file input field with a 'Browse...' button and a blue 'Submit' button below it.